


# TRIUMPH-B-2 Instruction Manual



1 6Pcs	2 ST4X30 6Pcs	3 2Pcs	4 ST4X12 6Sets	5 2Pcs
6 2Pcs	7 ST3.5X30 8Pcs	8 1Pc	9 2Pcs	10 2Pcs
11 L R 2Pcs	12 2Pcs	13 2Pcs	14 2Sets	15 2Pcs
16 1Pc	17			

## TOOLS REQUIRED

